

# Semote

Remote system for all Alexa cameras



On all Alexa models:

- network cable and radio control (range is 100-300 feet depending on line of sight)
- change/set and store 10 profiles for FPS, EI, WB and Shutter
- check all information on your own screen
- multi camera control
- start/stop camera
- switch 2K/HD
- toggle SxS 1 and 2
- turn Highspeed on/off
- change codec
- set Look
- set RecOut output
- set MonOut output
- turn REC OUT fps sets on/off
- playback with scrub forward/backward
- production ingest for scene and take
- load camera setups from sd card
- intervalometer
- store up to 10 camera IP addresses in remote unit
- easy firmware update via network cable



On Alexa Plus/Xr cameras:

- calibrate all lens motors and option to change motor direction
- roll/tilt display
- turn wrs radio on/off and set radio channel
- electronic horizon On/Off

<b>A</b>	<b>FPS</b>	<b>SHUTTER</b>	<b>STBY</b>
	25.000	180.0°	
	800	3200K 0	
18-03-2015	EI	WB	2K
<b>TC Int</b>	<b>REEL A001</b>		
19:42:11@25	CLIP C002 0:00:00		
<b>BAT 1</b>	-	SxS1 1:29:25	
<b>BAT 2</b>	15.4V	SxS2 ???	
<b>BATT</b>	8.0V	SxS LOG C	
<b>LINK</b>	WL (S9)	REC OUT REC 709	
		MON OUT REC 709	
		CODEC PR 4444	

On Alexa Studio

- Set Gate/View mode
- Turn Mirror On/Off
- Turn internal ND filter On/Off

Power source any Sony NP type or aftermarket 7.2V camcorder battery

DC power supply

SUP 11 tested

unlimited free firmware upgrades

